

## BOTTIES®

# Capri Mules



#### **Material required**

A pair of Botties basic soles, Pattern, Fabric for the upper, Suede or other soft fabric for the lining, scissors, Fusing , Thread, P.U. (Faux leather) for piping, Strong Adhesive.

Click on the link to download pattern

CAPRI MULE PATTERN

#### **Making Process**

Step 1- Print the pattern according to your shoe size by clicking the link provided.

Step 2- Trace the pattern on top of both upper and lining fabric. Don't forget the stitching and pasting allowances while tracing.

Step 3- Cut all parts carefully.

Step 4- Paste fusing in the upper fabric to get good strength.

Step 5- Paste lining and upper together

Step 6- Use matching P.U. (faux leather) or fabric for the edge piping and stitch the upper and lining together.

Step 6- Cover the botties insole by pasting contrasting colour fabric of your choice using a strong adhesive.

Step 7- Paste the upper with the insole by folding the allowance at the bottom with the help of adhesive.

Step 8- Using the nylon thread provided in the pack make a false stitch in the soles and join it with upper using a strong adhesive or directly stitch the upper part with the sole.

Step 9- Apply botties tags on the outside of your mules.

Step 10- Your perfect and easy to make botties are ready to wear.

### **TIPS & TRICKS**

- For more finished look give a false stitching and then attach the sole with upper with the help of a strong adhesive.
- You can try different stitching styles to make your botties look more beautiful.
- Paste the piping with help of glue before stitching to get a clean look.

