

## The Street of th

# PATCHWORK SHOES



#### **MATERIAL REQUIRED**

- 1. A pair of Botties basic
- 2. Pattern
- 3. Felt fabric for the upper(yellow & off-white)
- 4. Faux leather
- 5. Suede or other soft fabric for the lining
- 6. scissors
- 7. Fusing
- 8. Thread
- 9. Strong Adhesive.
- 10. Punch Plier

Click on the link to download pattern

PATCHWORK SHOES PATTERN

#### **INSTRUCTIONS**

- Step 1: Print the pattern For both upper & lining according to your shoe size by clicking the link provided.
- Step 2: Trace & cut pattern no.1,2,3,5 & 6 on faux leather, pattern no. 4 on yellow felt fabric, pattern no. 7,8 on off white felt fabric. Don't forget the stitching and pasting allowances while tracing.
- Step 3: Cut all the upper parts carefully.
- Step 4: Paste fusing in all the upper panels for reinforcement.
- Step 5: Stitch all the panels together as directed in the pattern.
- Step 6: Make cuts on the toe part and pass three faux leather strands through it (paste the extra allowance beneath).
- Step 7: Give zigzag top stich at the joining of each panel.
- Step 8: Trace & cut the lining panels out of contrasting suede fabric.
- Step 9: Stitch all the lining panels together.
- Step 10: Stitch the lining and upper together from the neck using stich and flip technique.
- Step 11: Make eyelets for lacing using punch plier.
- Step 12: Trace & cut tongue panels along with the allowances out of yellow felt fabric.
- Step 12: Stitch the tongue panels and attach it beneath the lining as per the placement shown in pattern sheet.
- Step 13: Cover the botties insole with the lining fabric using strong adhesive.

- Step 14: Paste the upper with the insole by pasting the allowance beneath insole with the help of adhesive.
- Step 15: Using the nylon thread provided in the pack make a false stitch in the soles and join it with insole using a strong adhesive or directly stitch the insole with the sole.
- Step 16: Apply botties tags on the outside of your shoes.
- Step 17: Your patchwork shoes are ready to wear.

### **TIPS & TRICKS**

- Join all the panels by aligning the centers.
- Join all the panels using all-pins and then stitch it all together to avoid ruckus.

